

### Your phone



- 1 Up and down keys**  
Located on the front of your phone - these can increase volume or scroll through menus and options.
- 2 Soft keys**  
These keys perform the function indicated by the text immediately above them on the display.
- 3 Quick Access key**  
The function of this key will vary depending on the mode of your phone. It provides quick access to a certain function such as SIM Toolkit or messaging.
- 4 Clear key**  
This erases characters or text or takes you back to your previous step, depending on the context. A long press on this key takes you back to the main screen.

### Making a call

#### Dialling a number

- Key in the area code and number that you want to call then press **Call** to dial.  
To delete the entire number and return to the main screen, press and hold **C**.
- You can adjust the earpiece volume in a call by using the front keys **Up** and **Down**.
- To end the call, press **End**.

#### Making an international call

- Press and hold **02** until the plus sign "+" is displayed. This replaces the international access code.
- Enter the country code, area code, and phone number.
- Press **Call** to dial.

#### Making an emergency call

- Enter 112 (or the local emergency number). Press **Call** to dial.

#### Making calls from the contact list

- Press **Contacts** from the main screen, you can also press **Contacts** then select the **Search** option.
- Type in the first letters of the name or scroll and find the one that you want.
- Press **Call** to dial.

#### Speed dialling

Allows you to dial a number simply by pressing and holding the assigned key from the main screen.  
To assign a contact list entry to a key: Press **Speed dial**, then press and hold one of the keys **1-9** until the key number appears on the left of the screen, beside the name. This indicates that the speed dial is successfully assigned.

#### Making a call from the calls list

The phone stores a list of your recent incoming, outgoing and missed calls. The list stores up to 30 entries.  
An icon on the left of the screen indicates the type of call:

- Incoming call
- Missed call
- Outgoing call

To dial a number from the redial/calls list: Press **Redial** to access the list. Scroll and find the one that you want and press **Call** to dial.

### Answering a call

#### Answering a call

To answer a call, press **Accept**. To reject a call, press **Reject**.

#### Call waiting

This feature means you are informed of a second incoming call by an audible tone in the earpiece.  
Press **Reject** to reject the second call. Press **Accept** to put the current call on hold and activate the second call. To end the active call and return to the held call, press **End**. To switch between calls, press **Swap**.  
**Note:** Your network may not support call waiting. If it does not, accepting a second call will end the first call. You will not be able to switch.

#### In call options

When you are in a call, you can press **Options**. These could be:

- Contacts**  
Gives you access to the contact list.
- Hold/Unhold**  
Puts the active call on hold/reactivates the held call.
- Mute/Unmute**  
Switches the microphone off/on.
- Send message**  
Allows you to send a text message.
- SIM Toolkit**  
Gives you access to the SIM Toolkit.
- Swap**  
Swaps between the current call and the call on hold.
- End all**  
Ends all calls.

### Ringer tone composer

Go into the **Sounds** menu and press **Options**.  
Change your ringer tones to personalise your phone. Create your own tones with our ring tone composer.

You have 2 entry methods.  
**Text** notes are entered textually.  
**Graphic** notes are entered on a musical score.  
Both entry methods use the same key presses unless stated.

- In this menu the keys represent the following notes:
- 1-9** C G
  - 2-9** D A
  - 3-9** E B
  - 4-9** F
  - 8-9** Enters a rest (text mode)
  - 9** Enters a rest (graphic mode)
  - 9-9** Changes the scale of the note between the range 1-4

#### Changing the duration of the note

- 02** Changes the duration of the note. Each press decreases the duration of the note between the range: full note, half note, quarter note, eighth note, sixteenth note and thirty-second note.
- 0** Changes a normal note to a sharp and a sharp back to a normal note.
- 02** Changes a normal note to a dotted, double dotted or 2/3 note. A long press will clear all notes.

**Tip:** A short press of the **0** and **0** keys will move you between notes in either entry mode.

Once you have composed the tone press **Options** to enter the menu screen. The available options are:

- Tempo:** Allows you to choose from a list of tempos at which to play your tone.
- Play:** Allows you to play your melody.
- Save:** Allows you to save your melody.
- Delete:** Allows you to delete the tone.
- Send:** Allows you to send your tone to one of your friends.

#### Receiving a ringer tone

If you have received a ringer tone press **Options** to enter the menu from where you can play, save or delete the tone. If you press **Options** the ring tone and message will be deleted.  
**Note:** It is only possible to save 5 ringer tones whether you have composed them yourself or received them as a message. To save more you will have to overwrite an existing ringer tone.

### Useful tips

#### Setting time and date

Enter the **Settings** menu to set the time and date. Go to **Set date** and press **Select**. Enter the date and press **OK**. Go to **Set time** and press **Select**. Enter the time in 24 hour format. Press **OK**. The date and time will be stored.

#### Alarm clock

You can use your phone as an alarm clock. Enter the **Settings** menu and press **Alarm**. Set the alarm to **On** and enter the time (in 24hr format) when you require the phone to ring. When it rings press **Off** to switch it off, or **Snooze** to stop the alarm for ten minutes. The alarm will then sound again.  
**Note:** The alarm will sound even if the phone is switched off. The phone will power on but you will not be able to receive or make calls. Once the alarm finishes the phone will switch off.

#### Equalizer

Enter the **Sounds** menu and select **Equalizer**. This menu allows you to alter the earpiece audio settings of your phone. Choose from these 3 settings for optimum audio quality:  
• **Treble • Normal • Bass**  
**Shortcuts**  
To lock/unlock the keypad, press **Options** from the main screen. To enter/exist silent mode press **Options** then **Options** from the main screen. To enter a pause while dialling press and hold **0** until the letter **p** appears. This will insert a pause of 3 seconds.

### Getting started

To use your phone, you must first insert the miniature SIM card supplied by your service provider, and then charge the battery.

#### Removing the back cover

Press down on the ridges below the clip and slide the cover back. Lift off.

#### Inserting the SIM card

Place the SIM in the phone, starting with the right side first, making sure that the golden contacts of the card are touching the contacts of the phone. Hold the SIM card in place and slide the metal plate to the right, in order to cover the left hand side of the SIM card.

#### Fitting the battery

Insert the battery with the label facing down. Align the tabs on the battery with the tabs on the back of the phone. Clip into place. To remove press on the clip and lift the battery out.

#### Charging the battery

Insert the connector on the charger lead into the connector at the base of the phone. Plug the charger into a mains AC socket. When charging commences, the battery icon will change into a charger cable icon. When the battery is fully charged, the battery icon will reappear and you can disconnect the charger.

#### Powering up/down

To switch the phone on: Press **Power**. If the phone asks for a PIN code: Enter the code that is supplied with the SIM card. The code will be displayed as asterisks. When complete, press **OK**.

Wait a few seconds while the phone searches for the network. Once the network has been found, the main screen appears and your phone is ready to be used. The main screen shows the network name and two icons giving the signal strength (top right) and battery level (top left). To switch the phone off, press and hold **Power**.

### Menu navigation

To enter the main menu, press **Menu** from the main screen.

**Scrolling**  
You can scroll from one menu to another using the front keys **Up** and **Down**. When you find the menu that you are looking for, press **Select** to go in. Press **End**, back or **Options** to return to the previous level.

#### SIM Toolkit

Your service provider may offer some special services or applications. The name of the menu may change to indicate the type of service, for example "Information". For more details, please contact your service provider.

### Messages

#### Calling your voice mail

When you have a new message in your voice mailbox, your phone displays either the voice mail icon **VM** in the main screen or a text message sent from the network. This depends on your service provider.  
Press and hold **1**. If the phone asks for the voice mailbox number, enter it and press **Call**. The number can be obtained from your service provider.

#### Reading a text message

When you receive a text message, the envelope icon is displayed at the top of the main screen.

- Press **Read** to display the new message directly from the main screen.
- To read old messages select **Read** from the **Messages** menu.
- Use the up and down keys **Up** and **Down** to scroll through the message.
- Press **Options** to access the following message options:  
**Delete** Removes the message.  
**Chat** Initiates a chat session.  
**Reply** Sends a text message to the sender.  
**Call** Calls the sender (or, if there is a number in quotes in the message, this number is called instead).  
**Save no.** Adds the sender's phone number to your contact list.  
**Time/date** Displays the date and time of the message.  
**Forward** Sends the message to someone else.

#### Sending a text message

You can send messages of up to 160 characters to another GSM phone.  
1 Enter the **Messages** menu and select the option **Send**.  
2 Type in a new message or select a message from a list of saved messages.  
3 When you have entered the text, press **Send**.  
4 Enter the destination phone number, or press **Contacts** and select a name from your contact list.  
5 Press **Send** to send the message.  
**Note:** If you reply to a message, you do not have to re-enter the number. This is done automatically.

#### Sending a Smiley SMS

Send a picture with your text message to compatible phones. All other phones will display an Internet style Smiley. Choose **Smiley**.

- Emotions
  - Celebrations
  - Sports
  - Animals
  - Others
- Select the Smiley you would like to use from one of these categories and press **Select**. The text is restricted to 156 characters to allow space for the Smiley.

#### Reading a Smiley SMS

When you choose a message that has a Smiley in it, the Smiley appears on the screen for 3 seconds or until a key is pressed. Then the message appears. After this time the message reads as normal. A message with a smiley attached has a **Smiley** icon if new and a **Read** icon if read.  
**Note:** If replying to or forwarding an SMS the Smiley will not display and only appears on a new message.

#### Message settings

This menu offers three options:  
**Status report** Allows you to set whether or not you wish to be informed when your correspondent has received the text message.  
**Centre number** Allows you to enter or change the service centre number for text messaging.  
**Voice mail** Allows you to enter or change your voice mail number.

#### Chat

Sendo chat allows you to send messages to another user and view both sent and received SMS messages for chat participants in a convenient Chat screen.

#### Starting a chat session

Enter the **Messages** menu and select the **Chat** option.  
Enter your chatname on the My chatname screen (this screen will not appear if you have already created a chatname).  
You will then need to enter the number of the person with whom you would like to chat, or alternatively you can press **Contacts** to go into the contact list.

You can edit your chatname by selecting My chatname from the **Contacts** menu. Select the **Consult** option and then press **Options**. Select the change option and edit the chatname.

#### Having a chat

To send a chat message enter the text in the chat editor field and the press **Send**. The sent text will then appear in the chat history field and is sent to the other chat participant as a standard SMS message.

#### Chat options

- Swap** changes the active area between the text entry field and the chat history field.
- Font size** select between normal and small font on the Chat screen.
- Exit** Exit the chat session.

#### Predictive Text Input

To save time when you are writing a text message, your phone has a feature which guesses the letters that you are typing and tries to complete the word.

This input method allows you to simply press each key once. For example, to write the name "Ross", press **7**, then **6**, then **7**, then **7**, just once each.  
The word may change as you type, but don't worry about what is on the screen until you have finished the word. Sometimes different words share the same sequence of key presses. If the finished word is wrong, press **02** to scroll through other possibilities. If the word that you are looking for is still not there, press **02** repeatedly to change the text mode to **ab** and enter the word again.  
After you have completed a word, press the space key **0** to enter the next word. Press and hold **0** to pick a symbol to insert from the character table.  
Some intelligent punctuation (including full stops, hyphens and apostrophes) are also available on **1-9**. The punctuation mark is completed when you enter the next keystroke.

#### Changing the editing mode

The current editing mode is indicated at the bottom of the screen by one of these icons:

- ab** Lowercase text mode
  - AB** Uppercase text mode
  - 12** Numeric mode
  - 19** T9 Text Input (lowercase)
  - 19** T9 Text Input (uppercase)
- You can switch between uppercase, lowercase, and numeric modes by repeatedly pressing **02**. You can switch to predictive T9 Text Input by repeatedly pressing **02**. These are the characters which come on the screen when you press the numeric keypad. They are featured in the table below:

Key	List of characters available
1	1 . @ ? ! " ' ; :
2	a b c 2 0 0 0 0 0 0 0 0 0
3	d e f 3 0 0 0
4	g h i 4 0
5	j k l 5
6	m n o 6 0 0 0 0 0 0 0
7	p q r s 7 0
8	t u v 8 0 0
9	w x y z 9
0	0
#	space

To enter two characters on the same key, enter the first one and then wait for the cursor to reappear before entering the second.  
**Example:** To enter the name "Ross", when you are in lowercase mode:

Press **02** to enter uppercase mode. Press **7** three times, to display "R". you will then return to lowercase mode. Press **6** three times, to display "o". Press **7** four times, to display "s". Then press **7** four times, to display "s".

#### Entering symbols

A long press on **0** displays a table showing all the symbols available to you. Scroll down the table to display more symbols.

1	2	3	4	5	6	7	8	9
;	:	-	/	?	@	[	]	;
&	;	:	/	?	@	[	]	;
*	=	<	>	£	€	¥	¢	¤
\$	£	€	¥	¢	¤	£	€	¥
W	Q	L	J	O	E	O	R	U
0	0	B	U	U	N	O	U	U

To enter a symbol:  
1 Scroll to the row containing the symbol you want.  
2 Press the numeric key (**1-9**) to reach the the symbol you want.  
**Example:** To enter the symbol €, scroll to the 4th row then press **3**.

### Troubleshooting

Problem	Possible cause	Possible corrective action
Phone does not power on	Battery empty Battery contacts dirty	Fully charge the battery and then press <b>Power</b> . Clean contacts on battery and phone with a dry cloth, attach battery, wait a few seconds and press <b>Power</b> .
Phone does not charge	Battery empty Charger incorrectly connected	Charge for 2 hours. Don't worry if the battery icon does not change immediately. Disconnect and try again. Check the mains socket, and the connection to the phone.
Battery	How long should I charge the battery the first time? I don't get as much battery life as I expected	12 hours continuous. The phone uses battery power when it is switched on even if it is not in a call. Making calls and playing with the different functions of the phone will run down the battery faster. The stated battery life is under optimum conditions.
"Insert SIM" is displayed when I switch on the phone	SM card is incorrectly inserted or missing SM card is damaged or dirty	Check that the SIM card is positioned correctly, and that the metal clip is slid across. Try again. Visually check the SIM and clean the contacts with a dry cloth. Try again. Enter the unlocking code supplied with the SIM card. If you do not have this code, contact your service provider.
The PIN code is blocked	3 incorrect entries	Enter the PIN2 unlocking code supplied with the SIM card. If you do not have this code, contact your service provider.
The PIN2 code is blocked	3 incorrect entries	Move to a warmer place and let the phone warm up. Contact your service provider.
Floor display	Low temperature	Move into an area of better coverage. If you are in a building, move towards a window.
Can't connect to network	Weak signal Invalid SIM card Network not allowed	Contact your service provider. Try reselecting the network. Switch off and then back on.
Can't make/receive calls	Weak signal Phone is switched off Check the number Call key not pressed Network is busy Call barring or fixed dialling is activated	Check that the service provider name is displayed on the screen. If not try to reconnect to the network. Press <b>Power</b> for a few seconds. Use the full area code and country code in the number. After dialling the number you must press <b>Call</b> . If you hear rapid beeps, then the network is busy. Hang up and try again. Check the fixed dialling settings. Otherwise check the call barring settings with your service provider. After purchasing your phone, you may need to call your service provider to activate the line. Recharge your credit.
Low earpiece volume	Low setting	Press <b>Options</b> when you are in a call to increase the volume.
Low ringer tone	Low setting	Go into the <b>Sounds</b> menu, select <b>Volume</b> and increase the setting.
Cannot enter some words	Wrong entry mode	Your phone has T9 text input (i.e. it guesses what words you are trying to enter). To enter a special word press <b>02</b> repeatedly to change to normal multi tap mode.
"Message list full" is displayed in the main screen	Your SIM card memory is full of text messages, therefore you can not receive any more messages.	Go into the <b>Messages</b> menu of the message menu and delete some of your messages.
Some features do not work	Feature not supported by the operator or your subscription.	Call your service provider.
Some menus are missing	There are restrictions on your SIM card or subscription.	Call your service provider.

## Safety information

You should observe and follow these guidelines for the safe and efficient use of your phone. Failure to comply with these guidelines and requirements may void your warranty and may invalidate any approvals given to your phone.

**Battery frequency signals**  
Your phone transmits and receives radio frequency (RF) signals whenever it is switched on. The design of your phone complies with all relevant standards and recommendations for human exposure to RF energy.

Your phone transmits power to control the cellular network at the lowest possible level to maintain a good signal. You may also choose to reduce your exposure to RF signals by controlling the duration of your calls or by using an accessory such as a handsfree device. Your phone has been designed to comply with applicable standards when used correctly in accordance with the user instructions. A sample of this phone model has been tested and found to comply with the following directives, standards or recommendations:

- 1999/5/EC • 93/336/EEC • 73/23/EEC as amended by 92/68/EEC • 1999/519/EC
- EN125137:21 (4) VDE • ENEC SA C53.1, 1999 Edition

**Antenna Care and Efficient Operation**  
Do not use your phone if the antenna is damaged. Replace the antenna only with one approved by the manufacturer. Unapproved antennas or modifications may damage your phone, degrade its performance and violate local regulations.

Do not touch the antenna unnecessarily while it is in progress. Contact with the antenna affects call quality and may cause your phone to transmit at a higher power level than otherwise needed. Hold your phone in any way you would any other phone. The antenna should point up and over your shoulder.

**Batteries**  
All batteries can cause property damage, injury or burns if a conductive material such as jewellery or keys comes into contact with the exposed terminals. The material may complete an electrical circuit and become quite hot. Exercise care in handling your phone battery.

For example, avoid carrying your phone battery loose in a pocket or purse. This product is designed for use with manufacturer-approved batteries only. Use of unapproved batteries may be dangerous and may cause damage to the battery or the phone and may void your warranty.

**Accessories**  
Only use accessories approved by the manufacturer. Using unapproved accessories with your phone may result in degraded performance, fire, electric shock or injury, and may void the warranty. Please check with your dealer for the availability of approved accessories. Your phone is intended for use only with chargers approved by the manufacturer.

Any other use will invalidate any approval given to your phone and may be dangerous. The main AC charger is compatible only with power sources indicated on its label. Do not connect the charger to a power source of a different voltage or frequency. Do not use the charger outdoors or in areas where it may become wet.

**Using the charger from the wall socket using the body of the charger, not the cord. Locate the cord so that it will not be tripped over, stepped on or damaged. Do not use the charger if it is damaged. Unplug the charger from the wall socket before cleaning it. Use a slightly damp cloth for cleaning, and allow the charger to dry fully before plugging it in.**

**Always:**  
Do not place your phone or any accessories in the area over an airbag or in the airbag deployment area. An airbag inflates with great force, and serious injury could occur.

**Always:**  
Switch off your phone when in an aircraft and follow any instructions from the aircraft crew. The use of cellular telephones

**Children**  
Your phone is not a toy. Do not allow children to play with it. They could hurt themselves or others. Children could also damage the phone or make calls that increase your telephone bill.

**Electronic Devices**  
Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

**Flammable Atmospheres**  
To avoid interfering with blasting operations, turn your phone off when in a potentially explosive atmosphere. It is rare, but your phone or its accessories could generate sparks. Sparks in such areas could cause an explosion or fire resulting in property damage, bodily injury or even death. Areas with potentially explosive atmospheres are often, but not always, clearly marked. They include:

- Fueling areas, such as petrol stations, below deck on boats, and fuel or chemical transfer and storage facilities.
- Areas where fuel colours are present, such as when gas leak occurs in a home.
- Areas where fire or contains chemicals or particles, such as grain, dust or metal powders.
- Any other area where you would normally be advised to turn off your phone.

**Heating Aids**  
Operation of any radio transmitting equipment, including your cellular phone, may interfere with some hearing aids. In the event of such interference, you may want to consult your cellular dealer or hearing aid manufacturer to discuss alternatives.

**Medical Devices**  
Operation of any radio transmitting equipment, including your cellular phone, may interfere with the functionality of inadequately protected medical devices. Consult your doctor or the manufacturer of the medical device if you have any questions. Turn your phone off in health care facilities when any regulations require that you do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

**Motor Vehicles**  
Using your phone in a vehicle demands special considerations. The fitting of any accessories to a vehicle should only be undertaken by a suitably qualified person to ensure that vehicle systems are not adversely affected, and that the accessory gives optimum performance.

**Warnings**  
RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles (e.g. electronic fuel injection systems, on-board braking systems and air bag systems). Check with the manufacturer or representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

**Disposal**  
Your battery and other components may require precautions to be taken for safe disposal. The battery type is indicated on the battery label. Please ensure that all local and/or governmental regulations are followed when you dispose of this product or its packaging. Refer to your point of sale or local government for information on regulations that apply to this product.

**Interference**  
Your phone is authorized for use in GSM networks in countries where it is approved. Use in other areas may be illegal and may disrupt other radio communications.

**Interference**  
Your phone is authorized for use in GSM networks in countries where it is approved. Use in other areas may be illegal and may disrupt other radio communications.

**Interference**  
Your phone is authorized for use in GSM networks in countries where it is approved. Use in other areas may be illegal and may disrupt other radio communications.

**Interference**  
Your phone is authorized for use in GSM networks in countries where it is approved. Use in other areas may be illegal and may disrupt other radio communications.

**Interference**  
Your phone is authorized for use in GSM networks in countries where it is approved. Use in other areas may be illegal and may disrupt other radio communications.

## Declaration of conformity

We: Sendo International Ltd  
CE 10th Floor AIA Plaza, 18 Hyatt Avenue,  
Causeway Bay, Hong Kong.

Declare under our sole responsibility that the product: S40220, known as 220 Identified by IMI numbers in the range: SAC: 330 741 F4C: 01 S4E: From: 000001 To: 499999

To which this declaration relates, is in conformity with the following standards: EN60950 (Electrical Safety Standard, IT equipment) EN 301 489 (Product standard for EMC)

ETSI 300 607-1 (GSM Phase 2 MS test specification) as defined in:

18K19 (as interpreted by G101 version 4.4)  
18K20 (as interpreted by G101 version 4.4)  
18K31 (as interpreted by G101 version 4.4)  
18K32 (as interpreted by G101 version 4.4)

ES 90020 (European Council Recommendation 1999/519/EC) We hereby declare that the above named product is in conformity with all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex IV of Directive 1999/5/EC has been followed with the involvement of the following notified body: BABS, Clewmoor House, 34 Maloney Road.

Walsley-On-Thames, KT12 4BD, England.  
Identification Mark: 168 (notified body number)

The technical documentation relevant to the above equipment will be held at Sendo Ltd, Camelskirk House, Tabour Way, Small Heath Industrial Estate, Birmingham, B10 0H England.

The authorized EU representative is:

*Michael Roger*  
Mike Roger  
Senior Approvals Engineer  
30/03/01

## Icons

### Symbol description

#### Main screen

**Battery indicator**  
Empty icon indicates a very weak battery level. Solid icon indicates a fully charged battery level.

**Battery charging**  
No bars indicates a very weak signal. Four bars indicates a very strong signal.

**Signal strength indicator**  
Four bars indicates a very strong signal.

**New text message**

**All incoming calls are diverted**

**Keypad locked**

**New voice mail message (this icon is network dependent)**

**Silent mode active**

**Alarm clock set**

**In calls list**

Shows that a call was incoming

Shows that a call was outgoing

Shows that a call was missed

**In messages list**

Indicates the messages which have not yet been read

Indicates the messages which have been read

Indicates the incoming messages which have not yet been read

Indicates the incoming messages which have been read

**Lists**

In lists shows the option that is currently activated

**Internet**

Returns you to the previous screen

Displays the current Homepage

## Services

### Commands

This menu allows you to send special commands to the network to get specific information. This could be information such as the time and date, your own phone number, or the amount of credit remaining on your SIM card. The commands, and whether this feature is available, can be obtained from your service provider. You can store the number of the command and a name. Once stored, scroll to the command and press **OK**. Send to get the required information from the network.

**Network selection**  
This menu allows you to choose how the phone searches for and then displays all available networks. If you are in manual mode then the selected network will become your default network.

**Send number**  
This menu allows you to select whether you hide your identity or not when you call someone.

**There are three options:**  
Network: Setting returns to Network default setting.  
On: Your telephone number is sent to your correspondent when you call.  
Off: Your telephone number is not sent to your correspondent when you call.

**You have two options:**  
**Automatic:** The phone searches all available networks and automatically selects one.  
**Manual:** The phone searches all available networks and, when finished, displays a list of all the networks found. You can scroll up and down with **Up** and **Down** to select the network that you wish to use. Once you select a network, your phone will always try to select this network. Network selection stays manual until you switch to automatic mode.

**Cost/timers**  
This menu contains all information on the amount of time you have spent on calls. **This menu offers five options:**  
**Balance:** Displays the amount of credit that you have left on your prepaid card.  
**Outgoing:** Displays the total time that you have spent on your phone on outgoing calls.  
**Incoming:** Displays the total time that you have spent on your phone on incoming calls.  
**Limit:** Allows you to view and set the maximum cost limit that you can go up to.  
**Rate:** Allows you to set the price per unit, and enter the currency in which you wish the call costs to be displayed.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

### Extras

#### Splash

Go into the Extras menu and select **Splash**. You will see an animated display. An incomplete curly pipeline is displayed starting at the top left of the screen and water is slowly flowing towards the open end.

The goal is to connect the open end of this pipe to the outlet at the bottom right of the screen before the water overflows!

To do this you are supplied with pieces of straight and bent pipe, which are shown at the right of the screen.

**Quaddro**  
Go into the Extras menu and select **Quaddro**. You can select the number of players: **Democratization** mode lets you watch the computer play against itself.

You against the computer. You against a friend.

**Tenpin**  
Go into the Extras menu and select **Tenpin**. The aim of the game is to knock as many of the pins down as possible.

To play the game press **OK** and the game will begin. The game is played over 10 frames and in each frame you have 2 attempts to knock down all of the pins. You can position the ball on the line by pressing **Up** or **Down** to move across the lane.

### Settings

#### Languages

This menu allows you to change the amount of time you have spent on calls. **This menu offers five options:**  
**Balance:** Displays the amount of credit that you have left on your prepaid card.  
**Outgoing:** Displays the total time that you have spent on your phone on outgoing calls.  
**Incoming:** Displays the total time that you have spent on your phone on incoming calls.  
**Limit:** Allows you to view and set the maximum cost limit that you can go up to.  
**Rate:** Allows you to set the price per unit, and enter the currency in which you wish the call costs to be displayed.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, **Reject**.

**Call waiting**  
When this function is activated, you can answer an incoming call by pressing any key, except **End**, <